



## Pressure Conversion Chart

	<b>B</b>				
<b>A</b>	<b>psi</b>	<b>Ins water gauge</b>	<b>kPa</b>	<b>bar</b>	<b>mm Hg</b>
<b>psi</b>	1	27.7	6.9	0.069	51.7
<b>Ins water gauge</b>	0.0362	1	0.249	0.0025	1.87
<b>kPa</b>	0.145	4.02	1	0.01	7.5
<b>bar</b>	14.5	401	100	1	750
<b>mm Hg</b>	0.0193	0.535	0.133	0.0013	1

To convert from a unit in column **A** to one in row **B** multiply by the factor in the corresponding box.

e.g. psi to bar = psi x 0.069